

DFX CUSTOM PROGRAM



	PROGRAM NAME	ROMAN
BASIC ADJUSTMENTS		
TARGET VOLUME		56
AUDIO THRESHOLD		8
TONE (AUDIO FREQ.)		220
AUDIO DISC.		ON
SILENT SEARCH		OFF
MIXED MODE		OFF
A.C. SENSITIVITY		70
D.C. SENSITIVITY		40
BACKLIGHT		0
VIEWING ANGLE		25
PRO OPTIONS		
AUDIO		
RATCHET PINPOINT		ON
S.A.T. SPEED		7
TONE I.D.		ON
V.C.O.		OFF
ABSOLUTE VALUE		
MODULATION		ON
G.E.B. / TRAC		
AUTOTRAC		ON
TRACVIEW		ON
AUTOTRAC SPEED		12
AUTOTRAC OFFSET		1
TRAC INHIBIT		ON
DISCRIMINATION		
BLOCK EDIT		
REJECT	-95	to -21
ACCEPT	-20	to +94
REJECT	+95	to
ACCEPT		to
REJECT		to
LEARN ACCEPT		OFF
LEARN REJECT		OFF
RECOVERY SPEED		22
BOTTLECAP REJECT		3
HOT ROCK REJECT		6
SWEEP SPEED		10
GROUND FILTERING		4
DISPLAY		
VISUAL DISC.		ON
ICONS		ON/OFF
V.D.I. SENSITIVITY		85
D.C. PHASE		OFF
GRAPH AVERAGING		ON
GRAPH ACCUMULATE		ON
FADE RATE		7
PREAMP		
PREAMP GAIN		*2
MULTI-FREQUENCY METHOD		
2 FREQUENCY (BEST DATA)		OFF
2 FREQUENCY (CORRELATE)		ON
V.D.I. NORMALIZED		ON
1 FREQUENCY (3kHz)		OFF
1 FREQUENCY (15kHz)		OFF

*Start at this position but adjust to as high a figure as the ground will allow whilst maintaining stability.